

tuforte[®]
adesivo



TECHNICAL DATA SHEET

TOPECA, Lda
Rua D. Nuno Alvares Pereira, 53
2490-114 Cercal – Ourém
PORTUGAL

Tel.: 00 351 – 249 580 070
Fax.: 00 351 – 249 580 079

TOPECA
FÁBRICA DE PRODUTOS PARA CONSTRUÇÃO

geral@topeca.pt
www.topeca.pt

tuforte
adesivo

masonry mortars

adhesive-plaster



- reference: slow or fast

use

Fitting and joining of plaster parts to plaster or cement based supports such as: skirting boards, frames, decorative elements, cornices, roses, friezes, corner pieces, columns, chapiters, fleurettes, balusters, plaster wall light fittings, niches and panels. Filling of cracks and holes.

surface

- plaster and/or cement based



CE marking

European standards
EN 12860



tuforte adesivo

adhesive-plaster

masonry mortars

recommendations

The quality of bonding depends on the amount of adhesive used. Do not add water after the paste has been prepared. Do not mix with other products (plaster, for example).

Place adhesive on both faces (part + support).

composition and characteristics

Composition:

Plaster, fillers and chemical additives.

Characteristics:

Application time – slow variety: 45 minutes

Application time – fast variety: 25 minutes

Time for fitting of parts: 10 minutes

Application temperature: 5 a 35°C

Pulp density: 1650 kg/m³

Reaction to fire: Classe A1

NOTE: Results obtained in our laboratory according to EN 12860. May vary with the conditions of application and type of support.

colour

White

consumption

1 Kg/ m_{linear}

available in

Sacks of 5 and 20 Kg.

Pallets with 48 sacks of 20 Kg

storage

1 year in unopened container and protected from moisture.



tuforte adesivo
adhesive-plaster

masonry mortars

preparation of surface

Supports must be clean and solid and dust free.
Rough out non-absorbent supports (e.g. paint).



application

Mixing is best carried out mechanically (at a slow speed). Add approx 10 litres of water for every 20 kg bag of Tuforte adesivo until a soft and even paste is obtained.



Using a spatula or trowel, spread Tuforte adesivo on the support and on the part to be bonded.



Apply firm pressure to ensure effective bonding takes place.



Remove any excess and smooth with a spatula.

